

# 4G<sup>+</sup> LTE RTK Bridge<sup>®</sup>-X

VERIZON MODEL

## STEP 1 - Activate your 4G LTE RTK Bridge<sup>®</sup>-X


Intuicom has partnered with Data Activation Center (DAC) to streamline the activation of your 4G LTE RTK Bridge-X. A SIM card has been provided by DAC for use with this device. Insert the SIM card into the slot on the front of your device. Confirm that it is inserted before going to STEP 2.

**To activate your 4G LTE RTK Bridge-X, call DAC toll free at 866-966-8881.**

For more specifics on activations please see the User Guide.

## STEP 2 - Attach Antennas

**!** Be sure to attach all antennas prior to powering on the unit.



## STEP 3 - Connecting to your Intuicom 4G LTE RTK Bridge<sup>®</sup>-X via WiFi:

- Turn on the WiFi enabled device you will use to access your RTK Bridge-X, such as a laptop, tablet, or smartphone.
- Locate your RTK Bridge-X wireless network under the list of available wireless networks. (e.g. Bridge-X140026)
- Select the wireless network named, Bridge-X(device serial #), and connect.
- You will be prompted to enter a security key. Default security key is the same as the Wireless Network Name.
- Open your Web browser and type in the IP address: <http://192.168.2.1>, this will take you to the login.

## STEP 4 - Login to your Intuicom Bridge<sup>®</sup>-X

Default Username: **admin**

Default Password: **serial number of device** (e.g. X140026)

## STEP 5 – Connection Verification is Accessible via the Status web page:

Clicking on "Help" accesses a Help index for all aspects of the product.

"Page Help" provides details and guidance on each specific page.

Active Internet connection status indicates valid activation and connectivity.

Internet Connection:	Connected ( 0 hrs, 0 min, 23 sec )
Current Internet IP:	166.255.35.200
Last Connect:	Tue Feb 14 23:40:38 UTC 2017
Last Disconnect:	Unavailable
# Connections:	1